Version 26.11.1 (2026-11-0X)

Changes

- Added relay settings for X-series units with relay option installed
- Added relay sequences to GPIO triggers and statuses
- Added battery backup for X-series units with battery module installed
- Added sACN and Art-Net settings editor for X-series
- Added network settings for both network interfaces for X-series
- Added unit type identifier to the unit view

Bug fixes

- Fixed X-series main input and channel supervision
- Fixed missing supervision indicator on X-series channel rows
- Fixed X-series channel LED ignoring the supervision state
- Fixed X-slot widget always rendering relays
- Fixed X-slots tab showing when no slot is fitted
- Fixed protection widget rendering when the module is absent
- Fixed main screen scrolling past the window height
- Fixed zero graph limits rendering as '/'

Version 26.7.1 (2026-07-22)

Changes

- Added settings for Xr and Xi new improved protection algorithms for dealing with transients
- Added warnings when saving potentially unsafe protection settings
- Added GPIO configurations for X-series units with GPIO support
- Added support for running multiple app instances in parallel
- Added warning on Windows when no IPv6-enabled network adapter is detected on startup

Bug fixes

- Fixed discovery failure caused by C-series units with older software
- Fixed discovery failing on unexpected and/or malformed responses
- Fixed an issue where protection settings did not close when going into another application view
- Fixed supervision thresholds not showing latest values on change
- Fixed text fields not submitting input on Enter key press
- Fixed automatic update checkbox losing state on firmware version change in dropdown
- Fixed and/or improved other minor UI components, naming and behaviour
- Fix issues that made API service crash

Version 26.1.1 (2026-02-03)

Changes

- Rebranded as StageSmarts Ampacity.
- Adds support for X-series (Xi and Xr).

Version 25.1.1 (2025-01-31)

First public release (StageSmart HMI).